

MoDOT's Workspace Configuration for PowerGeopak SS4

Follow the steps below to activate MoDOT's workspace.

1. Extract and place the MoDOT_Workspace on the root of the C drive.
2. Copy C:\MoDOT_Workspace\MoDOT_PowerGeopak_C-Drive.cfg to C:\ProgramData\Bentley\PowerGEOPAK V8i (SELECTseries 4)\WorkSpace\Standards\
3. Launch PowerGeopak SS4 with MoDOT's workspace configuration.

*** If you change the extraction location of the MoDOT_Workspace folder you will need to edit the MoDOT_PowerGeopak_C-Drive.cfg file and change the variable below to your new location.

USTN_DRIVE = C:/

